

Robotics 1


Trajectory planning

Prof. Alessandro De Luca

DIPARTIMENTO DI INGEGNERIA INFORMATICA AUTOMATICA E GESTIONALE ANTONIO RUBERTI



Trajectory planner interfaces



robot action described as a sequence of poses or configurations (with possible exchange of contact forces)



reference profile/values (continuous or discrete) for the robot controller



Trajectory definition a standard procedure for industrial robots



- 1. define Cartesian pose points (position+orientation) using the teach-box
- 2. program an (average) velocity between these points, as a 0-100% of a maximum system value (different for Cartesian- and joint-space motion)
- 3. linear interpolation in the joint space between points sampled from the built trajectory

examples of additional features

a) over-fly A


- b) sensor-driven STOP c) circular path
 - c) circular path through 3 points

....from 06_ProgrammingArchitectures block of slides (#5)

KUKA user interfaces



- Teach pendant
- KRL programming
- Ethernet RSI XML (12ms)



Fast Research Interface (1ms)



Fig. 4-1: Front view of KCP

- 1 Mode selector switch
- 2 Drives ON
- 3 Drives OFF / SSB GUI
- 4 EMERGENCY STOP button
- 5 Space Mouse
- 6 Right-hand status keys
- 7 Enter key
- 8 Arrow keys
- 9 Keypad

- 10 Numeric keypad
- 11 Softkeys
- 12 Start backwards key
- 13 Start key
- 14 STOP key
- 15 Window selection key
- 16 ESC key
- 17 Left-hand status keys
- 18 Menu keys

....from 06_ProgrammingArchitectures block of slides (#6)





basic instruction set:

Variables and declarations	
DECL	(>>> 10.4.1 "DECL" page 138)
ENUM	(>>> 10.4.2 "ENUM" page 140)
IMPORT IS	(>>> 10.4.3 "IMPORT IS" page 141)
STRUC	(>>> 10.4.4 "STRUC" page 141)
Motion programming	
CIRC	(>>> 10.5.1 "CIRC" page 143)
CIRC_REL	(>>> 10.5.2 "CIRC_REL" page 144)
LIN	(>>> 10.5.3 "LIN" page 146)
LIN_REL	(>>> 10.5.4 "LIN_REL" page 146)
PTP	(>>> 10.5.5 "PTP" page 148)
PTP_REL	(>>> 10.5.6 "PTP_REL" page 148)
Program execution control	
• • • • • • • • • • • • • • • • • • • •	
CONTINUE	(>>> 10.6.1 "CONTINUE" page 150)
CONTINUE EXIT	(>>> 10.6.2 "EXIT" page 150)
CONTINUE EXIT FOR TO ENDFOR	(>>> 10.6.2 "EXIT" page 150) (>>> 10.6.3 "FOR TO ENDFOR" page 150)
CONTINUE EXIT	(>>> 10.6.2 "EXIT" page 150) (>>> 10.6.3 "FOR TO ENDFOR" page 150) (>>> 10.6.4 "GOTO" page 151)
CONTINUE EXIT FOR TO ENDFOR GOTO HALT	(>>> 10.6.2 "EXIT" page 150) (>>> 10.6.3 "FOR TO ENDFOR" page 150)
CONTINUE EXIT FOR TO ENDFOR GOTO	(>>> 10.6.2 "EXIT" page 150) (>>> 10.6.3 "FOR TO ENDFOR" page 150) (>>> 10.6.4 "GOTO" page 151)
CONTINUE EXIT FOR TO ENDFOR GOTO HALT	(>>> 10.6.2 "EXIT" page 150) (>>> 10.6.3 "FOR TO ENDFOR" page 150) (>>> 10.6.4 "GOTO" page 151) (>>> 10.6.5 "HALT" page 152)
CONTINUE EXIT FOR TO ENDFOR GOTO HALT IF THEN ENDIF	(>>> 10.6.2 "EXIT" page 150) (>>> 10.6.3 "FOR TO ENDFOR" page 150) (>>> 10.6.4 "GOTO" page 151) (>>> 10.6.5 "HALT" page 152) (>>> 10.6.6 "IF THEN ENDIF" page 152)
CONTINUE EXIT FOR TO ENDFOR GOTO HALT IF THEN ENDIF LOOP ENDLOOP	(>>> 10.6.2 "EXIT" page 150) (>>> 10.6.3 "FOR TO ENDFOR" page 150) (>>> 10.6.4 "GOTO" page 151) (>>> 10.6.5 "HALT" page 152) (>>> 10.6.6 "IF THEN ENDIF" page 152) (>>> 10.6.7 "LOOP ENDLOOP" page 153)
CONTINUE EXIT FOR TO ENDFOR GOTO HALT IF THEN ENDIF LOOP ENDLOOP REPEAT UNTIL	(>>> 10.6.2 "EXIT" page 150) (>>> 10.6.3 "FOR TO ENDFOR" page 150) (>>> 10.6.4 "GOTO" page 151) (>>> 10.6.5 "HALT" page 152) (>>> 10.6.6 "IF THEN ENDIF" page 152) (>>> 10.6.7 "LOOP ENDLOOP" page 153) (>>> 10.6.8 "REPEAT UNTIL" page 153)
CONTINUE EXIT FOR TO ENDFOR GOTO HALT IF THEN ENDIF LOOP ENDLOOP REPEAT UNTIL	(>>> 10.6.2 "EXIT" page 150) (>>> 10.6.3 "FOR TO ENDFOR" page 150) (>>> 10.6.4 "GOTO" page 151) (>>> 10.6.5 "HALT" page 152) (>>> 10.6.6 "IF THEN ENDIF" page 152) (>>> 10.6.7 "LOOP ENDLOOP" page 153) (>>> 10.6.8 "REPEAT UNTIL" page 153) (>>> 10.6.9 "SWITCH CASE ENDSWITCH"
CONTINUE EXIT FOR TO ENDFOR GOTO HALT IF THEN ENDIF LOOP ENDLOOP REPEAT UNTIL SWITCH CASE ENDSWITCH	(>>> 10.6.2 "EXIT" page 150) (>>> 10.6.3 "FOR TO ENDFOR" page 150) (>>> 10.6.4 "GOTO" page 151) (>>> 10.6.5 "HALT" page 152) (>>> 10.6.6 "IF THEN ENDIF" page 152) (>>> 10.6.7 "LOOP ENDLOOP" page 153) (>>> 10.6.8 "REPEAT UNTIL" page 153) (>>> 10.6.9 "SWITCH CASE ENDSWITCH" page 154)

Inputs/outputs	
ANIN	(>>> 10.7.1 "ANIN" page 157)
ANOUT	(>>> 10.7.2 "ANOUT" page 158)
DIGIN	(>>> 10.7.3 "DIGIN" page 159)
PULSE	(>>> 10.7.4 "PULSE" page 160)
SIGNAL	(>>> 10.7.5 "SIGNAL" page 164)
Subprograms and functions	
RETURN	(>>> 10.8.1 "RETURN" page 165)
Interrupt programming	
BRAKE	(>>> 10.9.1 "BRAKE" page 166)
INTERRUPT	(>>> 10.9.2 "INTERRUPT" page 166)
INTERRUPT DECL WHEN D	(>>> 10.9.3 "INTERRUPT DECL WHEN DO" page 167)
RESUME	(>>> 10.9.4 "RESUME" page 169)
Path-related switching actions (=Trig	ger)
TRIGGER WHEN DISTANCE	(>>> 10.10.1 "TRIGGER WHEN DISTANCE" page 170
TRIGGER WHEN PATH	(>>> 10.10.2 "TRIGGER WHEN PATH" page 173)
Communication	
(>>> 10.11 "Communication" page 176)
System functions	

(>>> 10.12.1 "VARSTATE()" page 176)

basic data set: frames, vectors + DECLaration


Robotics 1

VARSTATE()


KRL language




typical motion primitives



PTP motion (point-to-point, linear in joint space)




CONST orientation




LIN motion (linear in Cartesian space)

end-effector orientation



CIRC motion (circular in Cartesian space)




PTP motion (linear in RPY angles)

Robotics 1

KRL language



 multiple coordinate frames (in Cartesian space) and jogging of robot joints





Trajectory definition a standard procedure for industrial robots



- 1. define Cartesian pose points (position+orientation) using the teach-box
- 2. program an (average) velocity between these points, as a 0-100% of a maximum system value (different for Cartesian- and joint-space motion)
- 3. linear interpolation in the joint space between points sampled from the built trajectory

examples of additional features

a) over-fly A

- b) sensor-driven STOP c) circular path
 - c) circular path through 3 points

main drawbacks

- semi-manual programming (as in "first generation" robot languages)
- limited visualization of motion




a mathematical formalization of trajectories is useful/needed

Some typical trajectories




Point-to-point Cartesian motion with an intermediate point



video

Straight lines as Cartesian path




video

Interpolation with Bezier curves

Some typical trajectories




Timing laws: Cartesian path with (dis-)continuous tangent



video

Square path at constant speed



video


Square path with trapezoidal speed profile

Robotics 1

Joint and Cartesian trajectories



 assigned task: arm reconfiguration between two inverse kinematic solutions associated to a given end-effector pose



- initial and final configuration
- same Cartesian pose (no change!): the motion cannot be fully specified in the Cartesian space
- to perform this task, the robot should leave the given end-effector pose and then return to it
- a self-motion could be sufficient
 - if there is (task) redundancy (m < n)
 - if the robot starts in a singularity

for "simple" manipulators (e.g., all industrial robots) and m=n, the execution of these tasks will require the passage through a singular configuration

Robotics 1


Joint and Cartesian trajectories



a reconfiguration task (or...



passing through singularity)




video

three-phase trajectory: circular path + self-motion + linear path

single-phase trajectory in the joint space (no stops)



From task to trajectory




example: TASK planner provides A, BTRAJECTORY planner generates p(t)

Trajectory planning

operative sequence






additional issues to be considered in the planning process

- obstacle avoidance
- on-line/off-line computational load
- sequence 2 is more "dense" than 1

Example





Cartesian space

Robotics 1 *15*



Path and timing law

 after choosing a path, the trajectory definition is completed by the choice of a timing law

$$p = p(s)$$
 $\Rightarrow s = s(t)$ (Cartesian space)
 $q = q(\lambda)$ $\Rightarrow \lambda = \lambda(t)$ (joint space)

- if s(t) = t, path parameterization is the natural one given by time
- the timing law
 - is chosen based on task specifications (stop in a point, move at constant velocity, and so on)
 - may consider optimality criteria (min transfer time, min energy,...)
 - constraints are imposed by actuator capabilities (max torque, max velocity,...) and/or by the task (e.g., max acceleration on payload)

note: on parameterized paths, a space-time decomposition takes place

e.g., in Cartesian space
$$p(t) = \frac{dp}{ds} \dot{s}$$
 $p(t) = \frac{dp}{ds} \dot{s} + \frac{d^2p}{ds^2} \dot{s}^2$

Trajectory classification



- space of definition
 - Cartesian, joint
- task type
 - point-to-point (PTP), multiple points (knots), continuous, concatenated
- path geometry
 - rectilinear, polynomial, exponential, cycloid, ...
- timing law
 - bang-bang in acceleration, trapezoidal in velocity, polynomial, ...
- coordinated or independent
 - motion of all joints (or of all Cartesian components) starts and ends at the same instants (say, t=0 and t=T) = single timing law or
 - motions are timed independently (according to the requested displacement and robot capabilities) – mostly only in the joint space

Cartesian vs. joint trajectory planning



- planning in Cartesian space
 - allows a more direct visualization of the generated path
 - obstacle avoidance, lack of "wandering"
- planning in joint space
 - does not need on-line kinematic inversion
- issues in kinematic inversion
 - \dot{q} and \ddot{q} (or higher-order derivatives) may also be needed
 - Cartesian task specifications involve the geometric path, but also bounds on the associated timing law
 - for redundant robots, choice among ∞^{n-m} inverse solutions, based on optimality criteria or additional auxiliary tasks
 - off-line planning in advance is not always feasible
 - e.g., when environment interaction occurs or when sensorbased motion is needed


Relevant characteristics



- computational efficiency and memory space
 - e.g., store only the coefficients of a polynomial function
- predictability and accuracy
 - vs. "wandering" out of the knots
 - vs. "overshoot" on final position
- flexibility
 - allowing concatenation of primitive segments
 - over-fly
 - ...
- continuity
 - in space and/or in time
 - at least C^1 , but also up to jerk = third derivative in time

A robot trajectory with bounded jerk





video

12 N

Trajectory planning in joint space

- q = q(t) in time or $q = q(\lambda)$ in space (then with $\lambda = \lambda(t)$)
- it is sufficient to work component-wise $(q_i \text{ in vector } q)$
- an implicit definition of the trajectory, by solving a problem with specified boundary conditions in a given class of functions
- typical classes: polynomials (cubic, quintic,...), trigonometric (cosine, sines, combined, ...), clothoids, ...
- imposed conditions
 - passage through points = interpolation
 - initial, final, intermediate velocity (or geometric tangent for paths)
 - initial, final acceleration (or geometric curvature)
 - continuity of time-(or space-)derivative up to the k-th order: class C^k

many of the following methods and remarks can be directly applied also to Cartesian trajectory planning (and vice versa)!

Cubic polynomial in space



$$q(0) = q_0$$
 $q(1) = q_1$ $q'(0) = v_0$ $q'(1) = v_1$ 4 conditions

$$q(\lambda) = q_0 + \Delta q(a\lambda^3 + b\lambda^2 + c\lambda + d)$$

$$\Delta q = q_1 - q_0$$
$$\lambda \in [0,1]$$

4 coefficients \longrightarrow "doubly normalized" polynomial $q_N(\lambda)$

$$q_N(0) = 0 \Leftrightarrow d = 0$$
 $q_N(1) = 1 \Leftrightarrow a + b + c = 1$

$$q'_N(0) = dq_N/d\lambda|_{\lambda=0} = c = v_0/\Delta q \quad q'_N(1) = dq_N/d\lambda|_{\lambda=1} = 3a + 2b + c = v_1/\Delta q$$

special case: $v_0 = v_1 = 0$ (zero tangent)

$$q'_N(0) = 0 \Leftrightarrow c = 0$$

$$q_N(1) = 1 \Leftrightarrow a + b = 1$$

$$q'_N(1) = 0 \Leftrightarrow 3a + 2b = 0$$

$$\Rightarrow a = -2$$

$$b = 3$$

Cubic polynomial in time



$$q(0) = q_{in}$$

$$q(T) = q_{fin}$$

$$\dot{q}(0) = v_{in}$$

$$\dot{q}(T) = v_{fin}$$

 $q(0) = q_{in} | q(T) = q_{fin} | \dot{q}(0) = v_{in} | \dot{q}(T) = v_{fin}$ 4 conditions

$$q(\tau) = q_{in} + \Delta q(a\tau^3 + b\tau^2 + c\tau + d)$$

$$\Delta q = q_{fin} - q_{in}$$
$$\tau = t/T \in [0,1]$$

4 coefficients \longrightarrow "doubly normalized" polynomial $q_N(\tau)$

$$q_N(0) = 0 \Leftrightarrow d = 0$$

$$q_N(1) = 1 \Leftrightarrow a + b + c = 1$$

$$q_N'(0) = dq_N/d\tau|_{\tau=0} = c = \frac{v_{in}T}{\Delta q}$$

$$q'_{N}(0) = dq_{N}/d\tau|_{\tau=0} = c = \frac{v_{in}T}{\Delta q} \quad q'_{N}(1) = dq_{N}/d\tau|_{\tau=1} = 3a + 2b + c = \frac{v_{fin}T}{\Delta q}$$

special case: $v_{in} = v_{fin} = 0$ (rest-to-rest)

$$q_N'(0) = 0 \Leftrightarrow c = 0$$

$$q_N(1) = 1 \Leftrightarrow a+b=1 q'_N(1) = 0 \Leftrightarrow 3a+2b=0$$
 $\Leftrightarrow a = -2 b = 3$





$$q(0) = q_{in}$$

$$q(0) = q_{in} | q(T) = q_{fin} | \dot{q}(0) = 0 |$$

$$\dot{q}(0)=0$$

$$\dot{q}(T)=0$$

boundary conditions (rest-to-rest)


$$q(\tau) = q_{in} + \Delta q \, \frac{1 - \cos \pi \tau}{2}$$


$$\Delta q = q_{fin} - q_{in}$$
$$\tau = t/T \in [0,1]$$




$$\dot{q}(\tau) = \frac{\Delta q}{T} \frac{\pi}{2} \sin \pi \tau$$

$$\dot{q}(\tau) = \frac{\Delta q}{T} \frac{\pi}{2} \sin \pi \tau$$
 $\ddot{q}(\tau) = \frac{\Delta q}{T^2} \frac{\pi^2}{2} \cos \pi \tau$







$$\max \dot{q}(\tau) = \dot{q}(0.5) = \frac{\Delta q}{T} \frac{\pi}{2}$$

$$\max |\ddot{q}(\tau)| = \ddot{q}(0) = -\ddot{q}(1) = \frac{\Delta q}{T^2} \frac{\pi^2}{2}$$





$$q(\tau) = a\tau^5 + b\tau^4 + c\tau^3 + d\tau^2 + e\tau + f$$
 6 coefficients
$$\tau \in [0, 1]$$

allows to satisfy 6 conditions, for example (in normalized time $\tau = t/T$)

$$q(0) = q_0$$
 $q(1) = q_1$ $q'(0) = v_0 T$ $q'(1) = v_1 T$ $q''(0) = a_0 T^2$ $q''(1) = a_1 T^2$

$$q(\tau) = (1 - \tau)^3 (q_0 + (3q_0 + v_0 T)\tau + (a_0 T^2 + 6v_0 T + 12q_0)\tau^2/2) + \tau^3 (q_1 + (3q_1 - v_1 T)(1 - \tau) + (a_1 T^2 - 6v_1 T + 12q_1)(1 - \tau)^2/2)$$

special case:
$$v_0 = v_1 = a_0 = a_1 = 0$$

$$q(\tau) = q_0 + \Delta q(6\tau^5 - 15\tau^4 + 10\tau^3) \qquad \Delta q = q_1 - q_0$$

Higher-order polynomials




- a suitable solution class for satisfying symmetric boundary conditions (in a PTP motion) that impose zero values on higher-order derivatives
 - the interpolating polynomial is always of odd degree
 - the coefficients of such (doubly normalized) polynomial are always integers, alternate in sign, sum up to unity, and are zero for all terms up to the power = (degree-1)/2
- in all other cases (e.g., for interpolating a large number N
 of points), their use is not recommended
 - there is a unique polynomial of degree N-1 interpolating N points
 - k-th degree polynomials have k-1 maximum and minimum points
 - oscillations arise out of the interpolation points (wandering)

Interpolating N = 2 knots







Interpolating N knots $q_1 \dots q_N$





$$N=2 \Rightarrow \text{a line}$$

$$q(\tau) = a_0 + a_1 \tau$$

= $q_1 + (q_2 - q_1)\tau$

$$N \Rightarrow$$
 a polynomial of degree $N-1$

$$q(\tau) = a_0 + a_1 \tau + \dots + a_{N-1} \tau^{N-1}$$

$$\tau = \frac{t}{T} \in [0,1]$$

$$N = 3 \Rightarrow a \text{ quadric}$$

$$q(\tau) = a_0 + a_1 \tau + a_2 \tau^2$$

$$a_0 = q_1$$


$$a_1 = \frac{(q_3 - q_1)\tau_m^2 - (q_2 - q_1)}{\tau_m(\tau_m - 1)}$$

$$a_2 = \frac{(q_2 - q_1) - (q_3 - q_1)\tau_m}{\tau_m(\tau_m - 1)}$$

$$\tau_m \in (0,1), \qquad q(\tau_m) = q_2$$

$$N = 4 \Rightarrow \text{a cubic}$$


$$q(\tau) = a_0 + a_1 \tau + a_2 \tau^2 + a_3 \tau^3$$



4-3-4 polynomials



three phases (Lift off, Travel, Set down) in a pick-and-place operation in time



boundary conditions

Interpolation using splines




- problem
 - interpolate N knots, with continuity up to the second derivative
- solution
 - spline: N-1 cubic polynomials, concatenated so to pass through N knots, and continuous up to the second derivative at the N-2 internal knots
- 4(N-1) coefficients
- 4(N-1)-2 conditions, or
 - 2(N-1) of passage (for each cubic, in the two knots at its ends)
 - $\blacksquare N-2$ of continuity for first derivative (at the internal knots)
 - \blacksquare N-2 of continuity for second derivative (at the internal knots)
- 2 free parameters are still left over
 - ullet can be used, e.g., to assign initial and final derivatives, v_1 and v_N
- presented next in terms of time t, but similar in terms of space λ
 - then: first derivative = velocity, second derivative = acceleration

Robotics 1

STORY SE

Building a cubic spline



$$\theta_k(\tau) = a_{k0} + a_{k1}\tau + a_{k2}\tau^2 + a_{k3}\tau^3 \qquad \tau = t - t_k \in [0, h_k]$$

$$(k = 1, \dots, N - 1)$$

continuity conditions for velocity and acceleration

$$\dot{\theta}_k(h_k) = \dot{\theta}_{k+1}(0)$$

$$\ddot{\theta}_k(h_k) = \ddot{\theta}_{k+1}(0)$$

$$k = 1, \dots, N-2$$

An efficient algorithm




1. if all velocities v_k at internal knots were known, then each cubic in the spline would be uniquely determined by

$$\begin{array}{ll} \theta_k(0) = q_k = a_{k0} \\ \dot{\theta}_k(0) = v_k = a_{k1} \end{array} \begin{pmatrix} h_k^2 & h_k^3 \\ 2h_k & 3h_k^2 \end{pmatrix} \begin{pmatrix} a_{k2} \\ a_{k3} \end{pmatrix} = \begin{pmatrix} q_{k+1} - q_k - v_k h_k \\ v_{k+1} - v_k \end{pmatrix}$$

2. impose the continuity for accelerations (N-2)

$$\ddot{\theta}_k(h_k) = 2a_{k2} + 6a_{k3}h_k = 2a_{k+1,2} = \ddot{\theta}_{k+1}(0)$$

3. expressing the coefficients a_{k2} , a_{k3} , $a_{k+1,2}$ in terms of the still unknown knot velocities (see step 1.) yields a linear system of equations that is always solvable





Structure of A(h)

$$\begin{pmatrix} 2(h_1+h_2) & h_1 \\ h_3 & 2(h_2+h_3) & h_2 \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & & \\ & & \\ & & & \\ & & \\ & & \\ & & & \\ &$$

diagonally dominant matrix (for $h_k > 0$) [the same tridiagonal matrix for all joints]



Structure of $b(\boldsymbol{h}, \boldsymbol{q}, v_1, v_N)$

$$\begin{pmatrix} \frac{3}{h_1h_2}(h_1^2(q_3-q_2)+h_2^2(q_2-q_1))-h_2v_1\\ \frac{3}{h_2h_3}(h_2^2(q_4-q_3)+h_3^2(q_3-q_2))\\ \vdots\\ \frac{3}{h_{N-3}h_{N-2}}(h_{N-3}^2(q_{N-1}-q_{N-2})+h_{N-2}^2(q_{N-2}-q_{N-3}))\\ \frac{3}{h_{N-2}h_{N-1}}(h_{N-2}^2(q_N-q_{N-1})+h_{N-1}^2(q_{N-1}-q_{N-2}))-h_{N-2}v_N \end{pmatrix}$$

Robotics 1

Properties of splines



- a spline (in space) is the solution with minimum curvature among all interpolating functions having continuous second derivative
- for cyclic tasks $(q_1 = q_N)$, it is preferable to simply impose continuity of first and second derivatives (i.e., velocity and acceleration in time) at the first/last knot as "squaring" conditions
 - choosing $v_1 = v_N = v$ (for a given v) doesn't guarantee in general the continuity up to the second derivative (when in time, the acceleration)
 - in this way, the first = last knot will be handled as all other internal knots
- a spline is uniquely determined from the set of data q_1, \dots, q_N , $h_1, \dots, h_{N-1}, v_1, v_N$
- in time, the total motion occurs in $T = \sum_k h_k = t_N t_1$
- the time intervals h_k can be chosen so as to minimize T (linear objective function) under (nonlinear) bounds on velocity and acceleration in [0, T]
- spline construction can be suitably modified when the second derivative (in time, the acceleration) is also assigned at the initial and final knots

A modification handling assigned initial and final accelerations



- two more parameters are needed in order to impose also the initial acceleration α_1 and final acceleration α_N
- two "fictitious knots" are inserted in the first and the last original intervals, increasing the number of cubic polynomials from N-1 to N+1
- in these two knots only continuity conditions on position, velocity and acceleration are imposed
 - ⇒ two free parameters are left over (one in the first cubic and the other in the last cubic), which are used to satisfy the boundary conditions on acceleration
- depending on the (time) placement of the two additional knots, the resulting spline changes ...



A numerical example

- N = 4 knots (o) \Rightarrow 3 cubic polynomials
 - joint values $q_1 = 0$, $q_2 = 2\pi$, $q_3 = \pi/2$, $q_4 = \pi$
 - at $t_1 = 0$, $t_2 = 2$, $t_3 = 3$, $t_4 = 5 \Rightarrow h_1 = 2$, $h_2 = 1$, $h_3 = 2$
 - boundary velocities $v_1 = v_4 = 0$
- 2 added knots to impose accelerations at both ends (5 cubic polynomials)
 - boundary accelerations $\alpha_1 = \alpha_4 = 0$
 - two placements: at $t_1' = 0.5$ and $t_3' = 4.5$ (×); or at $t_1'' = 1.5$ and $t_4'' = 3.5$ (*)

